

3. 如果产品长期(超过2个星期)不用,请对其充电; 4. 必须选择正规厂家生产且经过国家CCC认证的充电器 5. 若手机无法搜索到蓝牙耳机,请将蓝牙耳机重新进入配对 模式或将蓝牙耳机恢复出厂设置,若手机程序出错,请把 手机蓝牙关闭再开启或重启手机。 电池安全

1.请勿拆解或改装电池、插入异物、置入高温、或浸入水或其 它液体中,以免引起电池漏液、过热、起火或爆炸。电池只能由

制造商更换。 2.请勿跌落、挤压或穿刺电池。避免让电池遭受外部大的压力,

长时间使用耳机可能会造成听力损害,请合理安排

使用时间。

从而导致电池内部短路和过热。

低电量: 红灯10秒1闪

充电中: 红灯长亮 充满电: 白灯长亮

连接电脑或5V 1A的

USB适配器进行充电

0

池 0

期限为10年。

功能介绍

部件名称

电路板组件 ×

件一〇

充 电 线 X 0

本表格依据SJ/T 11364的规定编制

0:表示该有害物质在该部件所有均质材料中的

含量均在GB/T 26572 规定的限量要求以下。

X:表示该有害物质至少在该部件的某一均质材

料中的含量超出 GB/T 26572 规定的限量要求

使用年限

如本手册所述,在正常使用条件下,本产品的环保使用




































(可上下拨动)

机:长按多功能键约2秒

机:长按多功能键约2秒

○ 接听/挂断:单击多功能键

矩接电话:双击多功能键

● 语音互动:双击多功能键

● 通透模式:三击多功能键

₩ 上 一 曲: 上拨1.5秒多功能键

▶ 下 一 曲:下拨1.5秒多功能键 (+) 音量加:上拨一次多功能键 音量減:下拨一次多功能键

☑ 播放/暂停:单击多功能键播放/暂停

产品有害物质名称及含量

(Pb) (Hg) (Cd) (Cr(VI))

有害物质

0

(PBB)

0

铅 汞 镉 六价铬 多溴联苯



Type-C Cable User Manual QCY Era 5 Headphones Note: The images in this manual are for reference only and may vary from the actual product. Please refer to the actual product for accuracy. **FCC Statement** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency

However, there is no guarantee that interference will not occur in

a particular installation, If this equipment does cause harmful

interference to radio or television reception, which can be

determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of

--Increase the separation between the equipment and receiver.

--Connect the equipment into an outlet on a circuit different

-- Consult the dealer or an experienced radio/TV technician for

-- Reorient or relocate the receiving antenna,

from that to which the receiver is connected.

subject to the following two conditions:

the following measures:


operate the equipment.

Indicator LED Multi-Function Button

Type-C Charging Port

Overview

Packaging



Bluetooth Pairing

Dual-Device Connection

Long press for 2s to power on

1. Auto pairing mode when powered on,

Auto-reconnects to last paired device,

2.Search "QCY Era 5" and connect via Bluetooth.

3. To re-enter pairing mode, power off and hold the button for

Pairing mode: Red/white light flash alternately



Factory Reset

red light blinks 5 times.

Toggle down the button and hold for 10s

Charging Status

Red blinks 5 times

While powered on, toggle down the button for 10s until the

Use computer or 5V/1A Notice: This marking indicates that this product should not be disposed of with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.

Low battery: Red blinks every 10s

- Charging: Solid red

Fully charged: Solid white

Answer/End: Single press the button Reject call: Double press the button Previous track: Toggle up and hold the button for 1.5s (M) Next track: Toggle down and hold the button for 1,5s (+) Volume up: Toggle up the button Volume down: Toggle down the button Voice assistant: Double press the button Play/Pause: Single press the button Low-latency mode: Triple press the button Wireless frequency: 2,402~2,480GHz RF power of transmission: <4dBm The power delivered by the charger must be between min 2 Watts required by the radio equipment, and max 5 Watts in order to achieve the maximum charging speed. CE B & RoHS

Made in China

(b) Power on: Press and hold the button for 2s

(b) Power off: Press and hold the button for 2s

(Toggle Up and Down)

Controls

User's Phone User's Address Shop's Name

Model Number

Shop's Address

Date of Purchasing

manufacturer warranty from the date of delivery. Please

ensure you retain your purchase receipt. If any defects occur

due to quality issues within the warranty period, kindly bring

both the warranty card and the purchase receipt to the

authorized dealer for complimentary replacement services.

- The manufacturer's warranty is void under the following
- · Improper or inadequate maintenance or modification.

- The use of unspecified adapters and accessories.
- earthquakes, lightning, abnormal voltage, or environmental
- . Damages that occur as a result of one's failure to follow the
- · Accident, misuse, abuse, contamination, or other external (1)This device may not cause harmful interference, and interference that may cause undesired operation. · Malfunctions or damages resulting from natural disasters, Changes or modifications not expressly approved by the party
 - (2) This device must accept any interference received, including
 - responsible for compliance could void the user's authority to
- damage to the product. 8. Do not expose the product to extremely low or high temperatures (below 0°C or above 45°C). This device complies with part 15 of the FCC Rules, Operation is 9. Do not the product indicator light near the eyes of children

done by the manufacturer.

- - 10. Do not use the product during thunderstorms, as it may

overheating.

- cause abnormal operation and increase the risk of electric
 - 11. Do not use oil or other volatile liquids to clean the product. 12. Do not use this device for long periods of time and at high volume, as there is a risk of hearing

Bluetooth earbuds. If there is a phone program error, close

5. Do not disassemble or modify the battery, insert foreign

objects, expose it to high temperatures, or immerse it in water

or other liquids to prevent battery leakage, overheating,

ignition, or explosion. Battery replacement should only be

6. Do not drop, crush, or puncture the battery, Prevent

external pressure that may lead to internal short circuits and

7. Do not dismantle or modify the earbuds for any reason, as

it may result in fire, electronic breakdown, or permanent

and reopen Bluetooth on the phone or restart the phone.