


QCY-T17 直无线蓝牙耳机






使用前,请下载安装OCY手机APP客户端 以获得更便捷的且机操控体验

认识耳机

选择并组装耳套

中耳套适用于大多数人群,建议从中耳套开始试戴。





本说明书中的图片均为示意图,可能与实物有偏差,请以实

耳机配对

首次配对方法:

- 1、取出两只耳机,再将两只耳机放回充电盒中。合上充电盒 盖子。(此步骤为新机激活)
- 2、再次取出两只耳机。
- 3、刷新手机蓝牙设备列表,点击配对OCY-T17,完成配对。 *取出耳机自动开机,若未自动开机,请充电后重新尝试。


切换设备配对方法:

- 1、关闭A手机蓝牙,耳机自动断开进入配对模式。
- 2、刷新B手机蓝牙设备列表,点击配对QCY-T17,完成配对。
- *不支持同时连接两台手机,下次开机默认回连上次配对的手机



恢复出厂设置

耳机在充电盒里(开盖状态下),长按耳机按键10秒,白灯 闪5次, 白灯闪烁停止后复位完成, 请勿中途取出耳机。



充电盒亮灯提示


红灯: 耳机入仓长亮4S; 充电盒低电状态, 耳机入仓, 闪亮4下。

操作说明

佩戴耳机:



- 1.请正确佩戴左右耳机,戴上耳机后可微微转动调整,找 到个人舒适且稳固的位置。
- 2.麦克风口往下,朝嘴巴方向。
- 3.错误佩戴耳机会导致通话,听觉都受到不同程度的影响。



充电盒充电

充电中: 蓝色指示灯闪烁 充满电: 蓝色指示灯常亮

功能操作





€ 拒接电话:长按按键面板约1.5秒后释放 上 一 曲:长按左耳按键面板1.5秒

▶ 下 一 曲: 长按右耳按键面板1.5秒 ④ 语音助手: 三击左耳按键面板

播放/暂停:双击左/右耳按键面板播放/暂停

⑥ 低 延 迟: 三击右耳按键面板

OCY蓝牙耳机售后服务

- QCY蓝牙耳机售后服务承诺: 严格按照《中华人民共和国消费者权益保护 《中华人民共和国产品质量法》实行售后三包服务,服务内容如下: 在三包有效期内,您可凭购物凭证依照本规定享受免费的修理、更换、退货
- 1、自您购买之日起7日内,本产品出现故障,经由OCY售后服务中心确定为产品 质量问题,可享受修理、更换、退货的服务
- 2、自您购买之日起15日内,本产品出现故障,经由OCY售后服务中心确定为产 品质量问题,可享受修理或更换的服务。
- 3、自您购买之日起12个月内,本产品出现故障,经由OCY售后服务中心确定为 产品质量问题、可享受修理的服务。

售后服务与支持

- 充电仓指示灯

自产品购买之日起12个月(请妥善保管购买凭证)。

在产品保修期内,凡属产品本身质量引起的故障,请用户凭购买凭证与经销商取 得联系以享受售后服务。 如有任何产品损害或瑕疵非可归责干产品质量本身,则不在保修范围内。有下列 情形者不属于保修范围内

1、因天灾、地震、雷击、异常电压、环境因素而发生之故障或毁损的。

2、自行或委托未经原厂授权维修之厂商拆卸、改装或更换非原厂零件。

3、未按使用手册操作或因人为使用不当而造成损坏者,如产品浸水、腐蚀、掉 落、挤压或露在异常温湿度环境下。

三包凭证

产品信息:

产品型号	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_
订单编号	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_
用户信息	:																								
用户姓名	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_
联系电话		_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_
用户地址		_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_
退换货原因		_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_
购买信息	:																								
销售单位	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_

FAO

- 1.0: 只有一只囯机有声音怎么解决?
- A: 将两只耳机放回充电仓关盖, 再重新取出, 查看双耳是 否都有声音, 若还是只有单只耳机有声音, 请对两只耳 机恢复出厂设置。
- 2.0: 手机提示无法连接怎么解决?
- A: 将手机上的配对记录删除, 删除后重新进行搜索配对连 接即可。
- 3.0: 听歌/通话没声音怎么解决?
- A: 安卓手机在蓝牙连接名字的右边有个设置图标,点击进 入,关闭手机音频和媒体音频,再重新开启,若还是无 声,请将耳机重新与手机配对连接。
- 4.0: 为什么视频/游戏有延迟?
- A: 受使用环境、网络、手机编解码等因素的影响, 会引起 手机传送音频数据到耳机时有不同程度的延迟。
- 5.Q: 听到的声音卡顿/断续怎么解决?
- A: 在使用时若周围有大量的 Wi-Fi、5G/4G 信号、大功率 电器等等产生干扰,可能会引起卡顿、断续的情况,换 个环境或者重新配对连接就可以解决了。

若有售后服务需求, 请联系客服

电话: 4008-306-708 网址: www.qcy.com

制造商: 东莞市和乐电子有限公司 地址:广东省东莞市道滘镇粤晖路325号

提示

- 1. 使用产品前请仔细阅读本使用说明书并请妥善保管;
- 2. 首次使用时, 请先将本产品充满电;
- 3. 如果产品长期(超过2个星期)不用,请对其充电;
- 必须选择正规厂家生产且经过国家CCC认证的充电器;
- 5. 若手机无法搜索到蓝牙耳机, 请将蓝牙耳机重新进入配对 模式或将蓝牙耳机恢复出厂设置, 若手机程序出错, 请把 手机蓝牙关闭再开启或重启手机。
- 请勿以任何理由拆除或维修改装互机,否则可能会导致起火, 电子击穿甚至彻底损坏本品
- 请勿将产品置于温度过低或过高(0°C以下或45°C以上的环境 下):
- 请避免靠近儿童或动物的眼睛使用产品指示灯;
- 请勿在雷暴天气下使用该产品,雷暴可导致本产品工作不正 常,并增加触电的危险;
- 请勿用油及其他挥发性液体擦拭本产品;

注意: 长时间使用耳机可能会造成听力损害,请合理安排使用 时间。

产品有害物质名称及含量

	有害物质											
铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴 二苯醚 (PBDE)							
0	0	0	0	0	0							
X	0	0	0	0	0							
0	0	0	0	0	0							
X	0	0	0	0	0							
0	0	0	0	0	0							
	铅 (Pb) 〇 × 〇 ×	(Pb) (Hg) O O X O O O	報 汞 镉 (Pb) (Hg) (Cd) O O O O O O O O O O O O O O O O O O O	田 汞 镉 六价铬 (Pb) (Hg) (Cd) (Cr(VI)) 〇 〇 〇 〇 × 〇 〇 〇	田 汞 镉 六价格 多溴联苯 (Pb) (Hg) (Cd) (Cr(VI)) (PBB) ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○							

- 本表格依据SJ/T 11364的规定编制
- 0:表示该有害物质在该部件所有均质材料中的 含量均在GB/T 26572 规定的限量要求以下。
- X:表示该有害物质至少在该部件的某一均质材 料中的含量超出 GB/T 26572 规定的限量要求。

如本手册所述,在正常使用条件下,本产品的环保使用 期限为10年。

在此期间,产品不会泄露任何危险物质,本产品可以 同收,必须按照当地法规处理。













True Wireless Earbuds







For better using experience, please scan to download QCY app before start-up.

Overview

Choose Eartips

Please try medium eartips first as they fit most people.





Above pictures are for reference only yet practical accessories


How to Connect

First Time Pairing:

- 1. Pick up both earbuds, pop them back in case then close the lid to activate them.
- 2. Pick them up again
- 3. On cellphone, search for QCY-T17 and tap to connect.
- * Pick up earbuds to power on .Otherwise, please charge the case and try again.


Switch Paired Device:

- 1. Turn off phoneA's Bluetooth faculty and earbuds will auto disconnect and turn connectable
- 2. On phoneB, search for QCY-T17 and tap to connect.
- * Multi-point connection is not available. Earbuds will auto reconnect to phoneB uphon powering up again.



Factory Setting

Push earbuds into case, open lid and keep touching earbuds for 10s or until LED blinks white 5 times to reset eabuds(do not pick up earbuds during the process).



LED for Battery Level


LED will turn on red for 4s when earbuds are pushed in case; If battery level is low, LED will blink 4 times after earbuds are pushed in case.

Use Instruction

How to Wear



- fit vourself.
- 2. Keep microphone towards your mouth,
- 3. It will cause a bad calling or listening experience to wear them in a wrong way.




LED on Case

LED will blink blue when the case is charging and turn solid

blue once it is topped up.

Function



- (b) Power-on: pick up earbuds to power on
- (ii) Power-off: push earbuds into case
- Answer/end call: double touch panel
- (S) Ignore call: keep touching panel for 1.5s
- Skip track backward; keep touching left panel for 1.5s
- Skip track forward: keep touching right panel for 1,5s
- Voice assistant: triple touch left panel
- Playback/pause: double touch left/right panel to play/pause
- Low-latency mode: triple touch right panel

Warranty Card

Warranty Period

12 months after you purchase this item (or you may inquire your local shopper for more details),

ouch panel

Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service.

Model Nur	mber:								
Date of Pu	Date of Purchasing:								
User's Nar	ne:								
User's Pho	one:								
User's Add	dress:								
Shop's Na	me:								
Shop's Ad	dress:								
Comments	\$:								

Free exchange service will not be accessed under following

- 1. Damages caused unauthorized disassembly.
- 2. Defects or physical damages caused by leaking or dropping off.
- 3. Damages by act of God, Supposing your item is within any damages or defects except the above circumstances. please return to us or your distributor for free repairing.

FCC Statement

This equipment has been tested and found to comply with the imits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications, However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

from that to which the receiver is connected,

- -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different
- -- Consult the dealer or an experienced radio/TV technician

This device complies with part 15 of the FCC Rules, Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Tips

- 1. Before using the earbuds, please read the manual carefully and keep it for future references.
- 2. The earbuds need to be fully charged prior to first-time use.
- 3. If the earbuds are left unused for over two weeks, please
- 4. Please use the chargers made by qualified manufacturer.
- 5. If earbuds fail to be found by phone, please re-turn them connectable or restore factory settings. If a program error of phone occurs, please turn off and on Bluetooth function or reboot the phone.

Caveats

- 1. Never disassemble or modify your earbuds for any reasons to avoid any damages and danger.
- 2. Do not store the earbuds in extreme temperatures (under 0°C or over 45°C).
- 3. Avoid using the indicator close to the eyes of children or animals.
- 4. Do not use the earbuds during a thunderstorm to avoid dysfunction and increasing risk of electricshock. 5. Do not use harsh chemicals or strong detergents to clean
- the earbuds.

Note: please do not use earbuds for a long time as may damage your hearing.

Notes: Please arrange using time properly as your hearing may be damaged by using the device for a long time. Manufacturer: Dongguan Hele Electronics Co., Ltd. Address: No. 325 Yuehui Rd. Daojiao Town Dongguan City

Guangdong Province China











